

EN User manual for 1V227-4



Dear customer, Thank you for purchasing our product. For its safe and full functioning, please read these instructions carefully and adhere to them to avoid product misuse or damage. Please prevent unauthorized use of this appliance and always observe all rules for using electric appliances. Keep these instructions for future reference. This appliance is intended for home and outdoor use. Only adults shall use this appliance.

ON/OFF/Timer One press of the switch turns on the light in timer mode. Two presses turn on the light in normal (permanent) lighting mode, the third press turns off the light. **Timer** automatically turns the lights on and off. The timer works as follows. After activation, the lights are turned on for six hours. Then the lights are turned off for eighteen hours and this way all the time until you turn the timer off.

Power input 1: 3x AA 1.5V batteries. Insert the batteries according to the marking on the bottom of the battery case. For the best performance, use the alkaline batteries. Don't mix different types and/or old and new batteries. Always use new batteries of the same type.

Power input 2: Connect USB connector into USB adapter 5V (not included), or into a power bank.