

## **EN** User Guide for 1V241 Christmas lights



Dear customer, thank you for purchasing our product. Please carefully read and abide by the following instructions to ensure that this product is used safely and to your complete satisfaction. This will also help avoid any improper use or damage. Prevent any unskilled handling of the device and always follow the principles of use for electrical appliances. Store these instructions in a safe place.

**Power supply:** 3x AA batteries (alkaline recommended)

**Operating temperature:** -20°C to +50°C

### **Warning**

1. The product complies with protection class IP44 and is suitable for outdoor use.
2. To clean the lights, use a damp cloth and always turn it off first. Leave the lights to dry completely before using them.
3. This product is not a toy! Keep out of reach of children.
4. Protect the environment. When no longer usable, dispose of the product at the designed collection point. Do not discard with normal household waste.
5. The product should only be used by adults..

**Timer** automatically turns the lights on and off. After activation, the lights are turned on for 6 hours. Then the lights are turned off for 18 hours and this way all the time until you turn the timer off.

**Manufacturer:** Solight Holding s.r.o., Na Brně 1972, Hradec Králové 500 06, Czech republic