

EN Operating Instructions for Solight WN49



Battery: 3.7V 400mAh Li-Ion

Input: USB-C

Battery life min./max.: 1h/2h

Charging time: 2hrs

Number of light modes: 3 - 100% front, intermittent (flashing) front, 100% side

Coverage: IP44

Charging: plug the flashlight into a USB socket on your computer or a USB charging adapter. When charging, the red LED light will illuminate, once the flashlight is charged, the light will turn off.

The flashlight has an **adjustable light cone** (zoom). Change by pulling and retracting the head of the flashlight.

The light modes are switched by a button on the top of the flashlight, next to the USB input.

The light source of this luminaire is non-replaceable, at the end of its service life the entire luminaire must be replaced and disposed of in a designated place.

Manufacturer: Solight Holding, s.r.o., Na Brně 1972, Hradec Králové 500 06, Czech Republic