EN WO820-W/B | WO821-W/B
Gari LED lighting

Thank you for purchasing our product. Before installing, using or repairing the product, please read this manual carefully and pay attention to the safety warnings and instructions. This will ensure not only personal safety but also the long-term durability of the product.


Model numbers: WO820-W, WO820-B, WO821-W, WO821-B

INSTALLATION

1. Switch off the power supply.
2. Press the release buttons at both ends of the bracket
3. Remove the bracket.
4. Insert the wall plugs into the pre-drilled holes and screw the bracket into place.
5. Unscrew the four screws and open the terminal box cover.
6. Use the slider to select the light temperature (WW – warm white, NW – neutral white, CW – cool white).
   Connect the supply cable to the terminal block, ensuring the connections are correct. To secure the supply cable, unscrew the screws on one of the two (or both) clamps and thread the cable through. Then tighten the clamps.
7. Fit the luminaire onto the bracket.
8. Switch on the power supply.

WARNING

- Suitable for both outdoor and indoor use
- Prevent improper handling of this appliance and always follow the guidelines for using electrical appliances.
- Do not hang anything on the luminaire or cover it with anything.
- Keep the user manual in a safe place.
- Installation must only be carried out by a qualified technician
- Operating temperature: -20°C to 50°C.



The light source in this luminaire is non-replaceable; at the end of its service life, the entire luminaire must be replaced and disposed of at a designated collection point. This product contains a light source which, for design reasons, cannot be removed for inspection; therefore, the entire product is considered to be the light source. The power cable cannot be replaced; if it is damaged, the device must no longer be used.

A CE Declaration of Conformity has been issued for the product in accordance with applicable regulations.
Available on request from the manufacturer: info@solight.cz, or for download at www.solight.cz/en.

Solight Holding, s.r.o., Na Brně 1972, Hradec Králové 500 06, Czech Republic.